



## POP-UP CANOPY

### SET UP

1. Remove cover bag by lifting up and off the canopy frame. Set it aside where it can be replaced after the canopy is dismantled.



2. Gently pull legs apart to expand frame. Two people working on opposite sides makes the job easier. NOTE: Make sure the canopy is fully expanded before the next step.
3. Raise canopy fully by raising the sliders at the corners to the top of the legs. NOTE: Pins in sliders will “click” and lock when raised to proper level.
4. Adjust canopy height by raising legs to desired level. NOTE: Pins in legs will “click” and lock automatically.

### TAKE DOWN

Pull pins on legs to lower to the ground.  
Pull pins on all sliders to release truss system.  
Push legs together to compress frame back to original size. Lift legs to avoid bending.  
Replace cover over canopy frame.



## CAUTION



In the event of severe weather or high winds:  
DISMANTLE canopy immediately to avoid possible damage and/or possible injury.  
Keep all guests away from the canopy.  
DO NOT cook or grill under the tent.  
DO NOT attach anything to vinyl canvas.