



PARTY FOGGER

OPERATION

1. Insert remote controller into rear of the machine.
2. To avoid risk of electrical shock, insert cord plug into grounded outlet only. Indicator light on the remote controller will come on.
3. Fill reservoir with water based Fog Fluid.
4. Close cap tightly. Push clear plastic feeder tube down through the cap if there is slack.
5. When the indicator light on the controller comes on, the machine is ready to use.
6. At times the indicator light will go out. This is NORMAL. The machine is simply recycling. Depress the switch only when the indicator light is OFF.
7. Allow fog machine to cool down before packing for transportation.

SPECIFICATIONS

Tank capacity: 1 liter

Warm up time: approximately 5 minutes

Fog output: 3500cf/minute



CAUTION



ALWAYS make sure that there is enough fog fluid in the tank before turning it on. Activating the pump without fluid can cause damage to the machine. Vapor from this fluid may be irritating to some people with allergic sensitivity.

DO NOT expose, at close range, to known asthmatic.

Use in a well ventilated area.

To avoid injury from hot steam, keep at least two feet away from nozzle.

www.adamsrental.com

(609) 689-9500 • (908) 735-7368 • (800) 767-6386